

Instructions for use PROARGENTOL and PROARGENTOL GEL

PROARGENTOL is a ready-to-use cleaning agent for silver and silver alloys.

It is suitable e.g. for jewellery, coins or cutlery, i.e. any silver that should shine again.

Before treatment with PROARGENTOL, the silver part must be freed from any adhering grease or dirt particles. For this purpose, the silver part is first cleaned with hot soap or detergent solution.

Now PROARGENTOL is applied undiluted. The application is usually carried out as an immersion bath.

The vessel used for this must not be made of metal!

A glass, ceramic or enamelled vessel is recommended.

To improve the cleaning effect, the immersion bath can also be heated to approx. 50°C.

For larger parts, PROARGENTOL can also be applied with a brush, sponge or a standard spray bottle.

A medium-hard brush can also be used to assist during the cleaning process.

Depending on the type of silver (e.g. as an alloy) the application time of PROARGENTOL is longer or shorter. Pure silver can be cleaned the fastest.

When stored in a cool place, part of the active ingredient complex can settle on the bottom, which dissolves again when heated.

For container sizes from 5 l we take the used immersion bath back for disposal, please contact us by email.

Application of PROARGENTOL GEL

Apply the gel thickly to the silver object, the surface should be free of grease so that the active ingredient can easily reach the surface. The application time depends on the temperature and the thickness of the silver sulphide layer, it should be at least 15 minutes.

Tip:

To prevent the gel from drying out too much, the object to be cleaned can be covered with plastic foil or (in the case of smaller pieces) placed in a foil bag. After cleaning with PROARGENTOL, the metal surface can easily be brought to a high gloss with WASHING FLASH.

At the end of the reaction time, wash the gel with hot water.

Please note: Do not place parts that are not made of silver or are heavily silver-plated, such as knife blades and certain handle parts, in the dipping bath! Otherwise the steel blades could corrode !

Please turn around!

Safety Instructions:

Wear gloves when working with PROARGENTOL !

Make sure that no splashes get into the eyes. In this case, rinse immediately with plenty of water !

In general, all objects that have been cleaned with PROARGENTOL should be rinsed thoroughly!

Make sure that clothing is not wetted, otherwise textiles may be damaged.

Store protected from frost. Shelf life 36 months.

When working with chemicals, the usual precautionary measures must be observed !

Residues of the cleaning agent must be disposed of in accordance with the legal regulations ! (Pollutant mobile)



Danger warnings

H302 Harmful if swallowed. H351 May cause cancer. H361d Possible risk of harm to the unborn child. H411 Toxic to aquatic organisms, with long-term effects.

Fa. CSP – Chemische Spezialprodukte Olaf Günther

Pleißestraße 2 04416 Markkleeberg

Tel.: 01577/3237288

0341 46336843

<http://www.chema-shop.de>

Email: info@chema-shop.de